OCTAVARIUM

Analog Octaver - Synth - Envelope Filter

OPERATION

1 - Connect the input jack to your instrument

2 - Connect the output jack to your pedal chain or directly to amplifier

Octaver + Synth Side:

CLEAN: Clean Level (-inf/ +6Db) **SUB OCT:** Sub Octave Level(-inf/ +6Db) **SYNTH:** Synth Level (-inf/ +6Db)

VOL1: Master volume

Envelope filter Side:

TOUCH: Adjusts the opening threshold of the filter. FREQ .: Adjusts the frequency range of the filter **WAH:** Envelope level (only effect)

•• 000000

Amp

VOL2: Master volume

Rear Panel Connections: INPUT: Jack(Mono) **OUTPUT:** Jack(Mono) DC Adaptor (9v DC center negative)

- Clean, Sub Oct and Synth are 3 independent channels and you can mix them or use separately. After you can set the master volume.
- Wah knob of envelope filter sets only the FX volume. Clean level is already fixed.
- Vu-Meter displays the input signal level. Input signal up to 1V RMS is acceptable(white light). Red Light = clipping


IMPORTANT: Use only power supplies for musical instruments (e.g. One Spot or superior). FKT Audio decline any responsibility for the use of unstabilized or unsuitable power supplies.

Power Supply: 9v DC Current Flow: 60mA Switch: Buffer bypass Enclosure: Stainless steel 304 Weight: 750gr Wood Sides: Okoumè black Size: 170x110x42mm

9v DC Adaptor (center negative)

FKT AUDIO

Specifications:





Warranty

FKT Audio warranties the product to be free from defects in material and workmanship for a period of 3 years from the original date of purchase.

if the product fails within the warranty period, FKT Audio will repair or, at our discretion, replace the product at no cost to the original purchaser.

Exclusions

This warranty covers defects in manufacturing discovered while using this product as recommended by FKT Audio.

This warranty does not cover loss or theft, not does the coverage extend to damage caused by misuse, abuse, unauthorized modification, improper storage, lightning, or natural disasters.

Limits of Liability

In the case of malfunction, the product will be repaired or replaced, as described above. FKT Audio will not be liable to any party for damages arising from the failure of this product.

The following damages are not included: damage to other equipment and damages incidental to or arising from the inability to use this product.

