

SCARE CROW

Double Gain Overdrive

OPERATION

- 1 - Connect the input jack to your instrument
- 2 - Connect the output jack to your pedal chain or directly to amplifier

CONTROLS:

PRE-GAIN: Input stage linear gain (0 to +16dB)

GAIN: Overdrive stage linear gain (Switchable)

TONE: Active tone filter

VOL: Master volume

Rear Panel Connections:

INPUT: Jack(Mono)

OUTPUT: Jack(Mono)

DC Adaptor (center negative)

- Pre-Gain and Gain can be used together or separately
- Pre-Gain is the input stage and it is always active when you engage On-Off footswitch (White Led)
- Main Gain can be activated by left footswitch (red led) and it is subordinated to On-Off footswitch.
- You can also activate Gain switch before(to prepare the setup) and when engage the pedal(On-Off) you will have all stages active.
- To use only Gain you need to turn down Pre-Gain knob.



Specifications:

Power Supply: 9v DC

Current Flow: 20mA


Switch: Buffer bypass

Enclosure: Stainless steel 304

Weight: 400gr

Wood Sides: Okoumè black

Size: 110x110x42mm



IMPORTANT: Use only power supplies for musical instruments (e.g. One Spot or superior).

FKT Audio decline any responsibility for the use of unstabilized or unsuitable power supplies.



FKT AUDIO®

Warranty

FKT Audio warrants the product to be free from defects in material and workmanship for a period of 3 years from the original date of purchase. if the product fails within the warranty period, FKT Audio will repair or, at our discretion, replace the product at no cost to the original purchaser.

Exclusions

This warranty covers defects in manufacturing discovered while using this product as recommended by FKT Audio.

This warranty does not cover loss or theft, nor does the coverage extend to damage caused by misuse, abuse, unauthorized modification, improper storage, lightning, or natural disasters.

Limits of Liability

In the case of malfunction, the product will be repaired or replaced, as described above. FKT Audio will not be liable to any party for damages arising from the failure of this product.

The following damages are not included: damage to other equipment and damages incidental to or arising from the inability to use this product.

